


Model(s):
IS5000Z/D34

Wire Harness Part No's:
Main Harness - 47854
Gauge Harness - 46410
Coil Pack Harness - 47873



IGNITION SWITCH	
POSITION	CIRCUIT MAKE
1. OFF	G & M & A
2. RUN	B & L & A
3. START	B & L & S